

## Dual SRL Bracket


\* Patent Pending

Part #: 11058




### Attachment:

1. Open Dual SRL Bracket by simultaneously pressing release buttons at end of pin and at bracket loop.



2. Install compatible SRLs directly to bracket loop as shown. Do not install with carabiners. Maximum 2 SRLs per Dual SRL Bracket.

### Install close-up



Locking pin inserted through harness webbing under dorsal D-ring

SRLs connected to bracket loop

3. At webbing under harness dorsal D-ring, insert locking pin beneath webbing as shown.

Never connect Dual SRL Bracket to harness D-ring.

4. Fully close and lock Dual SRL Bracket. Ensure green indicator is fully visible when locked.



**ONLY for use with the following Guardian Fall Protection SRLs:**

Diablo Web SRL  
Diablo LE Cable SRL  
10' Cable Velocity SRL  
11' Halo Web SRL

**NEVER for use with any other fall protection device, unless explicitly permitted by Guardian.**



Green indicator fully visible