

• In addition to routine checks for each use, PPE should regularly undergo a detailed inspection by a competent person. Petzl recommends an inspection every 12 months and after any exceptional event in the life of the product.
 • PPE inspection should be conducted with the manufacturer's Instructions for Use.
 Download the instructions at PETZL.COM.



PULLEYS

User information

Surname

Address

Identifier

PPE information

Model

Serial number

Year of manufacture

Date of purchase

Date of first use

Manufacturer: Petzl, ZI Cidex 105A - 38920 Crolles - France

<input checked="" type="radio"/> Good condition (G)	<input type="radio"/> To monitor (TM)	<input type="radio"/> To repair (TR)	<input type="radio"/> Do not use, retire (R)	<input type="radio"/> N/A Not applicable
---	---------------------------------------	--------------------------------------	--	---

1. Known product history

Usage conditions or exceptional event during use (examples: fall or fall arrest, use or storage at extreme temperatures, modification outside manufacturer's facilities...):

<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	N/A
----------------------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----

2. Preliminary observations

- Verify the presence and legibility of the serial number and the CE mark.
- Verify that the product lifetime has not been exceeded.
- Compare with a new product to verify there are no modifications or missing parts.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

3. Checking the condition of the side plates

- Check the condition of the side plates (marks, deformation, cracks, wear, corrosion).
- Check the condition of the attachment holes (marks, deformation, cracks, wear, corrosion...).
- For pulleys with moving side plates, verify that the side plates rotate properly.
- Check the condition of the rivets (marks, deformation, cracks, corrosion, absence of play...).
- Check the condition (marks, deformation, cracks, wear, corrosion) and the rotation of the swivel in both directions.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

4. Checking the condition of the sheave(s)

- Check the condition of the sheave (marks, deformation, cracks, wear, corrosion, absence of foreign bodies...).
- Verify that the sheave turns freely in both directions.

Sheave on ratcheting wheel, SPIN L1D

- Check the condition of the ratcheting wheel (marks, deformation, cracks, wear, corrosion...). Verify that the sheave turns in the desired direction and blocks in the other direction.
- Count the number of clicks of the ratcheting wheel. You must hear 12 clicks during one complete rotation.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

5. Checking the side plates' opening and locking systems

- Check the condition and function of the locking system (marks, deformation, dirt, effectiveness of the return spring(s)).

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

6. Function check

- Install your pulley on an anchor and install a compatible rope around the sheave.
- Circulate the rope in both directions.

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

Comments (detail here any defects found on the product and accomplished tasks)

VERDICT

Product **fit** to remain in service

Product **unfit** to remain in service

Inspected by

Company

Date Next inspection date