



Fitting and Adjustment

Attach the two D-rings on the free ends of the straps to the descender connector either directly or using separate connectors. Adjust the straps so that the seat takes the load but the harness to descender connection is not slack. The buckles are easiest to adjust when the straps are slack, this can be done by sliding forward off the seat into The harness, adjusting the straps, then pushing the seat down and back under the thighs. (Fig 1)

Alternatively, the workseat can be connected to the central attachment point of the Matrix or Eclipse harness. Attach the connectors of the workseat to the central attachment point below the webbing belt to minimise webbing wear. (Fig 2)

When not required the seat may be conveniently carried diagonally across the back without removing it from the Harness. To do this slacken both straps then place one over one shoulder.

Markings

The date of manufacture is marked (as Batch no.) in the form DAY MONTH YEAR

The ID no. is unique to this item.

Maintenance

Maintenance is limited to regular inspection, cleaning and correct storage.

Wash by hand using pure soap or mild detergent in cool water.

Allow to dry away from direct heat. Do not store when wet.

Usage

All users must receive a copy of these instructions and be familiar with them.

All users must be suitably trained and competent to work in situations where a risk of falling may be present.

The heightec Group take no responsibility for injury or accident of any kind

Warnings

This item is not PPE, it is only to be used in conjunction with a suspension harness.

Ensure that the seat does not interfere with other items of equipment.

The side D-rings are for the attachment of accessories only and are not suitable for significant loads.



Fig 1



Fig 2

