Important: Practice and familiarise yourself with the use of this quick release leash before heading out on the water.

## **Fitting Instructions**

Firstly, attach the SUP Leash to the board

A larks foot hitch is a quick and easy way to attach to the board.







Thread the loop end of the SUP Leash through the board's D Ring, then thread the steel ring through the SUP Leash's loop. Pull all of the webbing through the loop to create a neat larks foot hitch.

The SUP Leash can now be used / worn in two different ways:

## 1. Quick Release Belt

Using the quick release section of our Guide or Gear Belts, thread the webbing end through the SUP Leash's ring and secure it in the cam buckle.



To release, pull the large cam buckle toggle. The SUP Leash will release easily and leave the belt in place, mounted on the waist.

## 2. Quick Release PFD:

Create a PFD mounted quick release system by fitting the SUP Leash Link to your Peak UK PFD's side straps. **We recommend only using the middle side strap**, as shown below:







**1-3:** Remove the webbing end terminal (and keep safe). Unthread the side webbing from the tension lock buckle. Thread the webbing through the small cam buckle, sliding it as far forward as required, and then close it tightly.







**4-6:** Rethread the side webbing through the tension lock, and pull it to achieve the desired fit. Feed the loose webbing end through the SUP Leash's ring and secure it in the quick release cam buckle.



**7-9:** The PFD mounted SUP Leash is now ready to use. To release, pull the cam buckle's yellow toggle. The SUP Leash will release, leaving the PFD's fit unaffected.

SUP Leash Link is compatible with the following Peak UK PFDs: Racer Pro, Racer Custom and Marathon Racer.